Manual Instruction

Precautions:

Ensure correct polarity of Cell. Insert the batteries in the correct direction by aligning the (—) marks on the batteries with the spring in the back cover.

When the megaphone is not in use for a long time, remove the dry cells. Drained cells or rechargeable battery will not give enough sound volume. Replace cells or charge the battery at regular intervals, for optimum result.

Operation:

Open the back cover by pressing the "Open Button". Insert 8 x "C" Cells or the battery and then close the back until it locks. Now your megaphone is ready for action. Press the on switch.

When using the megaphone, place your lips as close as possible to the megaphone. Adjust the Volume Control to the desired level without causing any howling or feedback.

When using the USB, SD, AUX function, adjust the switch to USB function on the handle, place the USB or SD card into the socket. When using the bluetooth function , press M button.

Adjust the volume control to the min, before recording. To begin recording press the REC button and the indicator light will turn on. Now your megaphone is ready for recording. Press the REC button after finishing your recording.

Features:

This megaphone is a compact design, with clear loud sound.

It is lightweight and portable, perfect for large meetings, assembly, propaganda...etc.

- ☒ Foldable Pistol Grip
- ☒ Talk Switch /Siren Switch / USB Switch
- ☒ Microphone has volume control
- ☒ ABS Plastic Construction
- ☒ Favorable Range: 500M
- ☒ Carry Strap

Technical Information

Requires 8X C batteries (not included)

Rated Power - 50Watts

Overall Length :350mm

Bell Width :250mm